



# FITTING INSTRUCTIONS

**VEHICLE** Any Tray Back Ute  
**MODEL YEAR** Any  
**PRODUCT** Auxiliary battery box  
**PRODUCT CODE** 008 A

## Battery Tray Details

Fits up to N70zz 12 inch case battery.

Comes with: 2 x backing plates with welded threaded bolts & nuts and 4 x 6mm bolts nuts and washers. As all trays are different thickness you may need to supply your own bolts.

1. Find desired position for battery tray, place battery tray and mark to drill holes.
2. Drill 4 holes in the top of the tray, place backing plates with welded 6mm threads through tray if suitable or use 4 x 6mm bolts nuts & washers and tighten.



3. Sit battery into box and place battery hold down on, then tighten until battery is firmly in place.