

VEHICLE Volkswagen Amarok
MODEL YEAR 2009 - onwards
PRODUCT Auxiliary battery box
PRODUCT CODE 025 E

Battery Tray Details

Fits up to N70zz 12 inch case battery or up to 120AH size 4x4 battery.

Comes with: 6 x 6mm bolts & nuts, 3 x 4mm bolts & nuts, 3 x washers, 1 x battery hold down with J hooks.

1. Assemble the bottom plate using 3 x 6mm bolts and place battery tray into desired position.

2. Mark holes and drill being careful not to drill into the tyre, and then tighten 3 x 6mm bolts nuts & washers into place.



3. Mark and drill the 3 top holes and tighten 3 x 4mm bolts into place with backing plate behind the lip of the tub.

4. Sit battery into tray and place battery hold down on the top inner corner of the battery, put J hooks into the corner holes in the battery tray and through the hold down then tighten until battery is firmly in place.