Fitting Instructions #1590BIS



Holden Commodore VE Strut Top Bushing

- o Jack the vehicle up and support on jack stands;
- o Remove the struts;
- o Remove original top strut bush with the use of suitable tools;
- o Install the new polyurethane top strut bush with the original washers;

Important Note: the washers need to be orientated as it is shown in the picture below*;

- o Refit the strut to the vehicle and tighten all bolts to manufactures torque settings;
- o Carry out a wheel alignment.

