

Fitting Instructions #RC0016RZ-20IS

Toyota Hilux / Mitsubishi Triton / Isuzu D-Max / Holden Colorado
Sway Bar Stabiliser Kit



Pictures are Generic and for instruction purpose only

Fitting of this bar should be carried out by qualified persons only.

- o Jack the Vehicle and place on support stands;
- o Fit the L Brackets, U-bolts, link pins and nuts as per the photo. **Do not tighten them;**
- o The wiring loom inside of the chassis rail needs moving out of the way to allow fitment (Use a zip tie or such to refit);

Note position of the RH bracket in the photo and match the LH side.



- o Fit the Sway Bar Mount bushings to the bar;
- o Place the Bar onto the top of the diff;
- o Place a stand under one side of the diff and remove the leaf spring U Bolts;
- o Remove the OE Bump stop;
- o Fit the new Bracket over the Bush and Mount them to the Diff using the OE U Bolts.
- o Nip up the U Bolts and Repeat for the other side;
- o Check the position of the bar making sure the arms are even both sides;
- o Tighten U bolts to manufacture's torque;



- Swing the bar up towards the rear and fit the sway bar links, bolts, nuts and washers provided to the bar. We recommend the middle hole is used initially;
- With the link approximately vertical tighten the Chassis U bolts.



Note: Rear facing sway bar.

Recheck positioning and Torque all bolts.

Please drive carefully to get used to the new handling characteristics.