

Fitting Instructions #TRC1000

Holden Commodore

VE Front lower control arm replacement kit



NOTE: *This kit must be fitted to both sides of the vehicle*

- Wheel-align the vehicle before the job is started and note settings;
- Jack the vehicle up and support on jack stands/hoist;
- Using factory manual, remove lower control arms from the front suspension;
- Replace the old lower control arm with TRC1000LH/RH arms from Superpro kit to the vehicle and tighten all bolts to manufacture's torque settings with arm in RIDE HEIGHT POSITION;
- Refit wheels and carry out wheel alignment;



Control arm must be tightened when arm is at ride height